



Bruksanvisning

Verdens Minste Lydmaskin[®]



Model S-002

sound oasis[®]

sleep better. feel better. live better.[®]

LEGG TIL NYE LYDER TIL DIN S-002!

For større valgfrihet og mer lydterapi kan du endre lydene i din "verdens minste lydmaskin" enkelt ved å bytte lydkort.

Nye lydkort er tilgjengelige på to ulike måter:

- (i) Du kan kjøpe ditt egne tomme mikro-SD-kort og laste ned S-002 lyder fra Sound Oasis' hjemmeside (www.soundoasis.com/custom-sound-cards). Så laster du inn de nye Sound Oasis lydene på ditt tomme mikro-SD-kort.

NB: Hvis du legger inn nye lyder på ditt medfølgende mikro-SD-kort vil du overskrive de medfølgende lydene som ligger der og de går da tapt.

eller

- (ii) Kjøp et selvvalgt mikro-SD-kort direkte fra Sound Oasis. Sound Oasis lager et lydkort til deg med de lydene du har valgt fra Sound Oasis' hjemmeside.

For mer informasjon om hvordan du kan kjøpe nye lydkort, vennligst besøk: www.soundoasis.com/custom-sound-cards.

Ditt SD-kort kan tas ut så du kan få andre lyder



INNHALDSFORTEGNELSE

- Legg til nye lyder til din S-002!.....2
- Introduksjon.....4
- Om din enhet.....4
- Viktig sikkerhetsinformasjon.....5
- Inkludert i pakken.....7
- Knapper og kontroller.....7
- Riktig bruk.....8
- Spille “Coaching Tracks”.....11
- Sleep Enhancement® teknologi.....12
- 30, 60, 90 minutters spilletid.....13
- LED-AV kontrol.....13
- Rengjøring.....14
- Tekniske spesifikasjoner.....15
- FCC Informasjon.....15
- Gjenvinning.....16
- Garanti.....17

Takk for at du valgte Sound Oasis®!

Sound Oasis® er verdensledende innen lydterapisystemer. Vi er opptatt av å gjøre livet sunnere og mer gledesfylt med kreative løsninger for lyd som kombinerer overlegen kvalitet med den aller nyeste teknologien.

Din Sound Oasis® verdens minste lydmaskin® vil hjelpe deg med å slappe av, lette innsovning, få bedre søvnkvalitet, mestre tinnitus og til og med forbedre din konsentrasjon gjennom dagen. Vår overlegne samling av lyder er utvalgt for å gi deg den beste mulige løsningen for dine spesifikke behov. Hvis du ønsker å legge til flere lyder kan du velge fra hundrevis av ulike lyder på Sound Oasis® hjemmeside.

Om din enhet

Din Sound Oasis® verdens minste lydmaskin® inkluderer 24 forskjellige lyder, samt disse nyttige egenskapene: ørepropper, lydutgang, Sleep Enhancement® teknologi, 30-60-90 minutters auto-av timer, innebygget oppladbart batteri, USB ladeport, ladeindikator, integrert lommeklips, volumkontroll, på/av knapp og deluxe reiseetui - alt i et produkt mindre enn din håndflate!

Viktig sikkerhetsinformasjon

- Les og ta vare på disse instruksjonene.
- Ikke bruk dette produktet i eller nært vann. Ikke eksponer den for regn eller fuktighet. Ikke plasser væskefylte objekter som eksempelvis en vase på produktet.
- Ikke plasser den på eller nær varmekilder som radiatorer, varmemålere, ovner, eller andre apparater (inkludert forsterkere) som produserer varme.
- Dette produktet inneholder et oppladbart lithium-ion-batteri som ikke kan byttes av brukeren. Modifisering av produktet, eller forsøk på å åpne det, vil føre til at garantien utgår og kan medføre risiko for egen sikkerhet.
- Lad batteriet ved hjelp av en datamaskin, strømhub, eller kraftkilde som er sertifisert av et anerkjent testlaboratorium.
- Lad batteriet i henhold til instruksjonene i denne bruksanvisningen.
- **FORSIKTIG:** For å minske risikoen for brann eller eksplosjon; unngå at batteriet eksponeres for overdreven varme slik som solskinn, ild eller andre varmekilder.
- Etter langvarig lagring kan det være nødvendig å lade opp og lade ut

batteriet flere ganger for å oppnå maksimal ytelse.

- Ved væskelekkasje fra batteriet unngå kontakt med hud og øyne. Hvis du likevel har fått det på deg, skyll med store mengder vann og kontakt helsevesenet for råd.
- Beskytt ladeledningen mot å bli tråkket på eller klemt, spesielt rundt kontaktene, og portene der ledningen kommer ut av produktet.
- Bruk kun tilbehør som er spesifisert av produsenten.
- Send alle forespørsler om service til kvalifisert personell eller kontakt Sound Oasis® på www.soundoasis.com eller 1-888-625-3218. Det er behov for service når produktet på noen måte har blitt skadet, slik som at ladeledning eller pluggen er skadet, væske har blitt sølt på produktet eller det har blitt truffet av en gjenstand, eksponert for regn eller fukt eller ikke fungerer som normalt.

Inkludert i pakken

Reiseetui

Lydmaskin og øreplugger

USB
ladekabel



Hovedfunksjoner

Sleep Enhancement* knapp

- Trykk for å slå Sleep Enhancement* på og av.

Auto-av timer

- Trykk for å velge kontinuerlig avspilling, eller 30, 60 eller 90 minutter spilletid.

Lade-/PÅ-indikator

- Lyser sterkt rødt under lading, svakt når ferdig ladet og grønt når enheten er påslått

USB ladeport

- USB ladekabel inkludert.

Lydutgang

- Bruk de medfølgende ørepluggene eller dine egne hodetelefoner.

Velg mellom lyder

- Trykk og hold for å slå enheten PÅ og AV.
- Trykk for å gå til neste lyd. 24 lyder er tilgjengelig.

Volumkontroll

- Trykk på høyre side for å øke volumet; trykk på venstre side for å senke volumet.

Mikro-SD-kort

- Uttagbart kort inneholder 24 lyder. Legg til nye lyder ved å sette inn nytt kort med andre lyder (se «Legg til nye lyder til din S-002!» i denne bruksanvisningen).

Lommeklips



- Egnert for å feste enheten til lommen, klærne, beltet osv.




Riktig bruk av «Verdens minste lydmaskin»®

Lade din enhet

Lad din enhet ved å plugge den lille enden av den medfølgende USB LADEKABELEN inn i din enhets USB LADEPORT og den større rektangulære enden av USB LADEKABELEN inn i en USB strømkilde.



- Den røde LADEINDIKATOREN vil lyse kraftig for å indikere at din enhet lader.
- Når batteriet er fulladet vil den røde LADEINDIKATOREN lyse veldig svakt eller være avslått.



NB: Du kan bruke andre USB-porter til å lade din enhet (for eksempel USB-porten på din datamaskin), men noen USB-porter har kanskje ikke nok kraft. Hvis du ikke ser den røde LADEINDIKATOREN lyse opp når USB LADEKABELEN er koblet til, prøv en annen USB-kilde eller bruk et støpsel med USB-port som strømkilde.

Bruk

Lyder på det inkluderte mikro-SD-kortet

Din «Verdens minste lydmaskin»® har 24 lyder som er lagret på det inkluderte uttakbare mikro-SD-kortet.

For større valgfrihet og mer lydterapi kan du endre lydene i din “verdens minste lydmaskin” enkelt ved å bytte lydkort.

Nye lydkort er tilgjengelige på to ulike måter:

- (i) Du kan kjøpe ditt egne tomme mikro-SD-kort og laste ned S-002 lyder fra Sound Oasis' hjemmeside (www.soundoasis.com/custom-sound-cards). Så laster du inn de nye Sound Oasis lydene på ditt tomme mikro-SD-kort.

NB: Hvis du legger inn nye lyder på ditt medfølgende mikro-SD-kort vil du overskrive de medfølgende lydene som ligger der og de går da tapt.

eller

- (ii) Kjøp et selvvalgt mikro-SD-kort direkte fra Sound Oasis. Sound Oasis lager et lydkort til deg med de lydene du har valgt fra Sound Oasis' hjemmeside.

For mer informasjon om hvordan du kan kjøpe nye lydkort, vennligst besøk:

www.soundoasis.com/custom-sound-cards.

Spille lyder

Trykk og hold inne SOUNDS-knappen en gang for å skru enheten på og starte avspillingen. LADEINDIKATOREN vil lyse grønt for å indikere at enheten er PÅ og spiller lyd.



Sounds-knappen

Enheden vil fortsette å spille lyder frem til du skruer den av ved å trykke og holde nede SOUNDS-knappen eller du setter enheten til å skru seg av etter 30, 60 eller 90 minutter.

For å velge en annen lyd, trykk på SOUNDS-knappen for å bla gjennom lyder til den lyden du vil ha blir spilt.

Justere lydvolument

Trykk på den høyre siden (◀)) av VOLUMKONTROLLEN for å øke lydvolument og trykk på venstre side (◀) av VOLUMKONTROLLEN for å senke lydvolument.



Volumkontroll

Spille “Coaching Tracks”

Noen Sound Oasis® lydspor inkluderer stemmespor for å hjelpe deg å sovne, slappe av osv. Vi kaller disse “Coaching Tracks”.

Når du spiller Coaching Tracks er det viktig at du trykker SLEEP ENHANCEMENT® knappen (☾) etter at du har valgt ønsket Coaching Track.



Å trykk på SLEEP ENHANCEMENT® knappen (☾) vil hindre at din enhet repeterer stemmesporet om og om igjen gjennom din sesjon.


NB: Sleep Enhancement vil ikke spille lydsporene saktere, slik den vanligvis gjør, når du spiller av Coaching Tracks.

Sleep Enhancement® teknologi

Sleep Center forskning har vist at en gradvis senkning av avspillingshastigheten hjelper til med bedre søvn og avslapning.

Vi har tatt denne forskningen og inkorporert denne spennende teknikken i din «Verdens minste lydmaskin»®. Når aktivert vil avspillingshastigheten på lydene på din enhet gradvis senkes for å forsiktig føre deg i søvn.

Når avspillingshastigheten har nådd sitt laveste punkt (nær halvparten av ordinær hastighet) vil hastigheten holde seg på dette nivået frem til enheten automatisk slår seg av (med 30, 60 eller 90 minutters timer) eller du manuelt slår av enheten.



Bruke Sleep Enhancement®

1. For å aktivere Sleep Enhancement funksjonen, trykk på SLEEP ENHANCEMENT knappen (☾). Når aktivert vil det grønne LED-lyset over SLEEP ENHANCEMENT® knappen (☾) lyse.
2. Enhver lyd du spiller mens Sleep Enhancement® funksjonen er aktivert vil bli gjenstand for Sleep Enhancement effekten.

3. For å slå Sleep Enhancement funksjonen av, trykk på SLEEP ENHANCEMENT knappen (☾). Det grønne LED-lyset over SLEEP ENHANCEMENT® knappen (☾) vil slukne.

30, 60, 90 minutters timer

Din enhet har 4 timer valg: 30, 60, 90 minutter og kontinuerlig avspilling. Når "30", "60" eller "90" minutter er valgt synker volumet gradvis de siste 10 minuttene før enheten slår seg. Dette er for å unngå en brå og forstyrrende slutt.

For å velge hvor lenge lyden du har valgt skal spille (30, 60, eller 90 minutter), press TIMER-knappen til det lyser over din foretrukne varighet.

NB: Når ingen av TIMER LED-lysene er tent betyr det at avspillingen vil være KONTINUERLIG.

LED av kontroll

Når AUTO-AV TIMER eller SLEEP ENHANCEMENT funksjonene er PÅ lyser de tilhørende LED-lysene. Det kan hende du opplever disse LED-lysene som for skarpe, spesielt når du skal sove. Du kan velge at LED-lysene kun skal være tent i 5 sekunder og deretter slå seg av ved å holde nede SLEEP ENHANCEMENT® knappen (☾) i omtrent 5 sekunder. LED-lysene vil blinke for å bekrefte valget ditt. For å endre


tilbake slik at LED-lysene er på under bruk, hold nede

SLEEP ENHANCEMENT® knappen (☾) igjen i omtrent 5 sekunder.

NB: Det grønne PÅ-LYSET plassert på bunnen av enheten vil være PÅ konstant under bruk.

Lydutgang

LYDUTGANGEN passer til en (3.5 mm) mono eller stereo type plugg. Du kan bruke ørepluggene som er inkludert, men du kan også bruke dine egne hodetelefoner.



Du kan også koble enheten din til putehøytalere eller høyttalerpute. Sound Oasis® har en rekke putehøyttaler-produkter å velge fra. Vennligst besøk www.soundoasis.com

Renhold

For å rengjøre produktet, tørk av med en myk klut kun fuktet med varmt vann eller mild såpe. Tørk så av med en tørr myk klut. Aldri bruk løsemidler eller sterke kjemikalier.

Tekniske spesifikasjoner

Batteri	Innebygget lithium batteri 3.7V/400mAh
Batteritid	15 timer
Ladetid	1 time
Ladespenning	5V +/- 0.25V
Størrelse	43mm bred; 55mm høy; 17mm dyp
Vekt (inkludert reiseetui)	128 g
Enhetsvekt	23 g
Lydport output	16 Ω 15 mW (single kanal)A

FCC Informasjon

Dette utstyret har blitt testet og er funnet å tilfredsstillende grenseverdiene til en klasse B digital enhet, i henhold til del 15 av FCC reglementet. Disse grenseverdiene skal gi rimelig beskyttelse mot skadelig interferens i en boliginstallasjon. Enheten genererer, bruker og sender ut radiobølger, og hvis den ikke brukes i henhold til instruksjonene kan den føre til skadelig interferens på radiobasert kommunikasjon. Man har uansett ingen garanti for at interferens ikke vil inntreffe i en gitt installasjon. Hvis denne enheten fører til

skadelig interferens på radio eller fjernsynssignaler, noe som kan avgjøres ved å skru enheten av og på, oppfordres brukeren til å rette på problemet med ett eller flere av følgende tiltak:

- Snu eller flytt mottakerantenna
- Øk avstanden mellom enheten og signalmottakeren
- Koble utstyret til en strømkrets annen enn den som mottakeren er koblet til.
- Kontakt forhandleren eller en kyndig radio/TV-tekniker.

Denne enheten tilfredsstiller del 15 av FCC reglementet.

Drift er underlagt til følgende to betingelser:

1. Denne enheten kan ikke forårsake skadelig interferens.
2. Denne enheten må godta all mottatt forstyrrelse, inkludert forstyrrelser som kan forårsake uønsket drift.

GJENVINNING

Kvitt deg med alle delene av produktet i henhold til lokale bestemmelser. Hvis du er i tvil om reglementet må lokale myndigheter kontaktes.

Det oppladbare lithium-batteriet i din enhet må gjenvinnes. Ikke forsøk å erstatte

det innebygde batteriet selv.



Symbolet med kryss over søppelbøtte betyr i EU at dette produktet må tas til et sted som samler inn slikt utstyr når det har nådd enden av sin levetid. Produktet skal ikke kastes i restavfall.



Li-ion



Ett års begrenset garanti

Sound Oasis Company garanterer at dette produktet er fritt for defekter i materialer og produkttilvirkning i ett (1) år fra kjøpsdatoen.

Hvis produktet ikke yter i samsvar med produsentens spesifikasjoner, returner det det stedet du anskaffet det eller ring vårt gratisnummer under innen ett (1) år fra anskaffelsesdato. Kvittering eller annet bevis på anskaffelsesdato er påkrevd.

Sound Oasis Company vil, etter eget valg, reparere eller erstatte produktet kostnadsfritt.

Denne garantien dekker ikke skader som er oppstått som følge av uhell, feilbruk eller misbruk, mangel på forsiktighet, tilkobling

av annet utstyr enn det som medfølger, tap av deler, eller dersom produktet har vært utsatt for annen ladespenning eller batterier spesifisert i denne bruksanvisningen.

Denne garantien er i stedet for annen garanti, uttrykkelig eller underforstått, inkludert all underforstått garanti for salgbarhet eller egnethet til spesielle formål, er begrenset i varighet til ett (1) år fra anskaffelsesdato. Ikke under noen omstendighet vil Sound Oasis Company være ansvarlig for tilfeldige skader, følgeskader eller spesielle skader grunnet bruken av dette produktet.

Noen stater tillater ikke begrensning i hvor lenge en underforstått garanti varer og/eller utelukkelse eller begrensning av ansvaret ved tilfeldige skader eller følgeskader. I så fall vil de ovenstående begrensninger ikke gjelde for deg.

Denne garantien gir deg spesifikke juridiske rettigheter som varierer fra stat til stat.

For å snakke med en Sound Oasis Kundeservice representant vennligst ring: 1-866-625-3218 eller send epost til info@soundoasis.com.

Besøk oss på www.soundoasis.com

Takk for at du valgte Sound Oasis®!



Instruction Manual

World's Smallest Sound Machine®



sound oasis®
sleep better. feel better. live better.®

ADD NEW SOUNDS TO YOUR S-002!

For greater variety and extra sound therapy, you can change the sounds on your World's Smallest Sound Machine® by simply changing the sound card!

New Sound Cards are available two different ways:

- (i) You can purchase your own blank micro SD card and download S-002 sounds from the Sound Oasis web site

(www.soundoasis.com/custom-sound-cards).

Then load the new Sound Oasis sounds onto your blank micro SD card.

Note: If you record new sounds on your existing sound card, it will erase the existing sounds.

or

- (ii) Purchase a custom made micro SD card directly from Sound Oasis. Sound Oasis will prepare a custom made Sound Card for you with every sound selected by you from the Sound Oasis web site.

For further information on purchasing new Sound Cards, please visit www.soundoasis.com/custom-sound-cards.

Your SD Card is removable so you can change sounds



TABLE OF CONTENTS

- Add New Sounds to Your S-002!....20
- Introduction.....22
- About Your Unit.....22
- Important Safeguards.....23
- What Is Included.....25
- Key Buttons & Controls.....25
- How to Use.....26
- Playing “Coaching Tracks”.....29
- Sleep Enhancement® Technology...30
- 30, 60, 90 Minute Timer.....31
- LED Off Control.....31
- Cleaning Instructions.....32
- Technical Specifications.....33
- FCC Information.....33
- Disposal.....34
- Warranty.....35

Thank you for choosing Sound Oasis®!

Sound Oasis® is the world leader in sound therapy systems and electronic sleep masks.

We are dedicated to making life healthier and more enjoyable with creative solutions that combine superior quality with the very latest technology.

Your Sound Oasis® World's Smallest Sound Machine® will help you relax, fall asleep easier, get higher quality sleep, manage tinnitus and even improve concentration during the day. Our unsurpassed collection of sounds are selected to give you the best possible solution to your specific needs. If you want to add new sounds, you can choose from hundreds of different sound options from our Sound Oasis® web site.

About Your Unit

Your Sound Oasis® World's Smallest Sound Machine® includes 24 different sounds plus these useful features: earbud headphones, headphone jack, Sleep Enhancement® technology, 30-60-90 minute auto shutoff timer, built-in rechargeable battery, USB power jack, charge indicator, integral pocket clip, volume control, on/off button and deluxe travel case - all in a product smaller than the palm of your hand!

Important Safeguards

- Read and keep these instructions.
- Do not use this product in or around water. Do not expose it to rain or moisture. Do not place objects filled with water, such as a vase, on the product.
- Do not place on or near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- This product contains a rechargeable lithium-ion battery which is not user replaceable. Tampering with your product, or attempting to open it, will void the warranty and can result in a safety hazard.
- Charge the battery using a computer, powered hub, or power supply that is certified by a recognized testing laboratory.
- Charge the battery in accordance with the instructions supplied in this user manual.
- CAUTION: To reduce the risk of fire or explosion, do not expose battery to excessive heat such as sunshine, fire or other heat sources.
- After extended periods of storage, it may be necessary to charge and discharge

the battery pack several times to obtain maximum performance.

- In the event fluid from the battery leaks from the product, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with generous amounts of water and seek medical advice.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the product.
- Only use attachments/accessories specified by the manufacturer.
- Refer all servicing to qualified service personnel or contact Sound Oasis® at www.soundoasis.com or 1-888-625-3218. Servicing is required when the product has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the product, the product has been exposed to rain or moisture or does not operate normally.

What is Included

Travel Case



Sound Machine & Earbud Headphones



USB Charge Cable



Key Features

Sleep Enhancement[®] Button

- Press to turn Sleep Enhancement[®] on or off.

Auto-Off Timer

- Press to select continuous or, auto shut-off time in 30, 60 or 90 minutes

Charge /On Indicator

- It is bright red when charging; dim when charged and green when unit is on

USB Charge Port

- USB charge cable included

Headphone Jack

- use included earbuds or your own headphones

Sound Selection Button

- Press and hold to turn unit ON and OFF.
- Press to skip to the next sound. 24 sounds available.

Volume Control

- Press right side to increase volume; press left side to decrease volume

Micro SD Card

- Removable card contains 24 sounds. Add new sounds by inserting a new card containing different sounds (see Purchasing New Sounds section of this user manual).

Pocket Clip



- Great for attaching to pocket, clothes, belt, etc.




How to Use Your World's Smallest Sound Machine®

Charge Your Unit

Charge your unit by plugging the small end of the included USB CHARGE CABLE into your unit's USB CHARGE PORT and larger rectangular end of the USB CHARGE CABLE into a USB power source.



- The red CHARGE INDICATOR will illuminate brightly to indicate your unit is charging.
- When the battery is fully charged, the red CHARGE INDICATOR will be off or very dim.



Note: You can use other USB ports to charge your unit (e.g. your computer USB port), but some USB ports may not have enough power output. If you do not see the red CHARGE INDICATOR illuminate when the USB CHARGE CABLE is connected, try another USB source or use a wall charger with USB port as a power source.

To Operate

Sounds On The Included Micro SD Card

Your World's Smallest Sound Machine® contains 24 sounds which are stored in the included, removable micro SD card.

For greater variety and extra sound therapy, you can conveniently insert a new Sound Card that has a different selection of sounds.

New Sound Cards are available two different ways:

(i) Purchase your own blank micro SD card and download S-680/S-002 sounds from the Sound Oasis® web site (www.soundoasis.com/custom-sound-cards). Then load the new Sound Oasis sounds onto your blank micro SD card.

or

(ii) Purchase a micro SD card directly from Sound Oasis®. You can purchase a “ready made” Sound Card or we can prepare a custom made Sound Card for you with every sound selected by you from the Sound Oasis® web site (but Sound Oasis® puts these sounds onto a micro SD card for you).

For further information on purchasing new Sound Cards, please visit www.soundoasis.com/custom-sound-cards.

Playing Sounds

Press and hold the SOUNDS button once to turn the power on and start playback of music. The CHARGE INDICATOR will show green to indicate that the unit is ON and playing sound.



Sounds Button

The unit will continue to play sounds until you turn the unit off by pressing and holding down the SOUNDS button or you set the unit to shut off in 30, 60 or 90 minutes.

To select a different sound, press the SOUNDS button until the sound of your choice is played back.

Adjusting Sound Volume

Press the right side (◀)) of the VOLUME CONTROL to increase sound volume and press the left side (▶) of the VOLUME CONTROL to reduce sound volume.



Volume Control

Playing “Coaching Tracks”

Some Sound Oasis® sound tracks include voice tracks for help falling asleep, relaxing, etc. We call these “Coaching Tracks”.

When you play Coaching Tracks, it is important that you press the SLEEP ENHANCEMENT® button (☾) after you select the Coaching Track.




Pressing the SLEEP ENHANCEMENT® button (☾) will stop your unit from repeating the voice tracks over and over throughout your session.

Note: Sleep Enhancement slowing of sounds will not be active during playing of Coaching Tracks.

Sleep Enhancement® Technology

Sleep Center research has proven that a gradual slowing of sounds helps promote better sleep and relaxation. We've taken that research and incorporated this exciting technique into your World Smallest Sound Machine®. When activated, the playback speed of your unit's sounds will gradually slow down to gently lull you to sleep.

Once the playback speed reaches its slowest point (close to one half of normal speed), the playback speed will remain at this level until the unit automatically turns itself off (with the 30-, 60- or 90-minute timer) or until you manually turn the unit off.



Using Sleep Enhancement®

1. To activate the Sleep Enhancement feature, press the SLEEP ENHANCEMENT button (☾). Once activated, the green LED above the SLEEP ENHANCEMENT® BUTTON (☾) will illuminate.
2. Any sound that you play back while the Sleep Enhancement® feature is activated will experience the Sleep Enhancement effect.

3. To turn the Sleep Enhancement feature off, press the SLEEP ENHANCEMENT button (☾). The green LED above the SLEEP ENHANCEMENT® BUTTON (☾) will turn OFF.

30, 60, 90 Minute Timer

Your unit has 4 timer options: 30, 60, 90 minutes and continuous playback. On the “30”, “60” and “90” minute timer positions, the sound gradually fades away during the last 10 minutes before the unit turns itself off to avoid a jarring off.

To select the length of time you want your sound to be played (30, 60, or 90 minutes), press the TIMER button until you see your desired timer position illuminated.

Please note: When in CONTINUOUS mode, no TIMER LED is lit.

LED Off Control


When your AUTO-OFF TIMER or SLEEP ENHANCEMENT features are ON, the LED indicators for each feature will be illuminated. You may find these LED indicators too bright, especially during sleep. You can choose to have the LED indicators stay on for only 5 seconds and then go dark by pressing down and holding the SLEEP ENHANCEMENT® BUTTON (☾) for about 5 seconds. The LED indicators will flash to confirm your selection.

To have the LED indicators stay on during use, just press down and hold the SLEEP ENHANCEMENT® BUTTON (⏪) again for about 5 seconds.

Note: The green ON INDICATOR located on the bottom of the unit will stay ON constantly during use.

Headphone Jack

The HEADPHONE JACK accepts a 1/8" (3.5 mm) monaural or stereo type plug. Earbud headphones are included for your use, but you can use your own headphones.



You can also connect your unit to pillow speakers or a speaker pillow. Sound Oasis® has a number of pillow speaker products to choose from. Please visit www.soundoasis.com

Cleaning Instructions

To clean, gently wipe with a soft cloth moistened with warm water or mild detergents only, and then remove all moisture with a soft, dry cloth. Do not use harsh solvents or chemicals for cleaning.

Technical Specifications

Battery	Built-in lithium battery 3.7V/400mAh
Run Time	15 hours
Charging Time	1 hour
Charging voltage	5V +/- 0.25V
Dimensions	1.7"/43mm wide; 2.2"/55mm height; 0.7"/17mm deep
Weight (including travel case)	4.5 oz. / 128 g
Unit weight	0.8 oz. / 23 g
Earphone Jack Output	16 Ω 15 mW (single channel)A

FCC Information

This equipment has been tested and found to comply with the limits for a class B digital Device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur

in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

DISPOSAL

Dispose of all product parts in accordance with local regulations. If in doubt, please consult your local authorities.

The rechargeable lithium battery in your unit needs to be recycled. Do not attempt to replace the built-in battery yourself.



The crossed-out wheeled bin means that within the European Union the product must be taken to separate collection at the product end-of-life. Do not dispose of these products as unsorted municipal waste.



Li-ion



1 Year Limited Warranty:

Sound Oasis Company warrants that this product is free from defects in materials or workmanship for a period of one (1) year from the date of original purchase.

If the product fails to operate in accordance with the manufacturer's specifications, simply return the product to the retail location where you purchased it or call our toll free number below within one (1) year of the date of purchase. Proof of date of purchase is required. Sound Oasis Company will, at its option, repair or replace the product at no charge to you.

This warranty does not cover damage resulting from accident, misuse or abuse, lack of reasonable care, the affixing of any attachment not provided with the product, or loss of parts, or subjecting the product to anything but the specified voltage or batteries.

This warranty is in lieu of any other warranty, express or implied. All implied warranties, including any implied warranty of merchantability or fitness for any particular purpose, are limited in duration to one (1) year from the date of original purchase. In no event will Sound Oasis Company be responsible for incidental, consequential, or special damages resulting from the use of this product.

Some states do not allow limitation on how long an implied warranty lasts and/or the exclusion or limitation of incidental or consequential damages, so the above limitation may not apply to you. This warranty gives you specific legal rights, which vary from state to state.

To speak with a Sound Oasis Customer Service Representative, please call: 1-866-625-3218 or email us at info@soundoasis.com.

Visit us at www.soundoasis.com

Thank you for choosing Sound Oasis®!